

# Vasco Digipass 270<sub>Xpress</sub>

## Getting Started



## Content

<b>1. What is a Vasco Digipass 270Xpress</b>	<b>3</b>
<b>2. Prepare your Digipass</b>	<b>4</b>
<b>4. Authorisation with your Digipass</b>	<b>7</b>
<b>5. Unlock your Digipass</b>	<b>8</b>

The information contained herein is the property of Deutsche Bank Group and may not be copied, used or disclosed in whole or in part, stored in a retrieval system or transmitted in any form or by any means (electronic, mechanical, repro-graphic, recording or otherwise) outside of Deutsche Bank Group without prior written permission.

## 1. What is a Vasco Digipass 270<sub>Xpress</sub>

The Vasco Digipass 270<sub>Xpress</sub>\* (Digipass) is a PIN protected personal identification device which is used for the login and/or payment authorisation process. Upon entering a personalised PIN, the Digipass token generates a unique code. This unique code acts as your 'digital signature' and allows you to login to your Deutsche Bank systems and manage your online payments.

- 1 Switching on your digipass  + 
- 2 Clearing or confirming digits 
- 3 Confirming your PIN code when logging in 
- 4 Confirming your PIN Code when authorizing 



\*Please note that the displayed Token is a Vasco Digipass 270<sub>Xpress</sub>. Different support collateral exists for Vasco DigipassXH as well as Vasco Digipass 300. If you are currently using a Vasco Digipass 300 kindly contact your Deutsche Bank representative.

## 2. Prepare your Digipass

Prior to using the Digipass for the first time, you have to set it up. For this you will require the PIN code that was initially provided to you by Bank. The PIN code needs to be changed, before you can use it further.

### 2.1. Changing your PIN Code

- Compare the serial number of your Vasco Digipass, located on the back of the device at the bottom, with the serial number on the letter you received along with your PIN code. (Note: If these two numbers do not match, please contact our helpdesk)



- Switch on your Digipass: Press and Hold
- Enter the PIN code you received from Deutsche Bank. If you make a mistake, press  to clear the digits and then start again.



- Enter a five-digit PIN code of your choice. If you make a mistake, press  to clear the digits. Do not choose a code that is easy to guess, such as 12345. If you enter such a code, you will see a warning on the display saying 'NOT SAFE'.



- Re-enter your chosen five-digit PIN code for confirmation.



- 'NEW PIN CONF' appears on the display after you have successfully entered your new PIN code.



- Your Vasco Digipass is now ready to use.


### 3. Login with your Vasco Digipass

If you want to login to Deutsche Bank's Autobahn App Market with your Vasco Digipass, you will need your Username and PIN code (the one you chose, see previous chapter).

If you are using the Autobahn App Market platform for the first time, you will find your User ID on the letter accompanying your PIN code. If you have previously logged in to the site, you can continue using your existing user name.

- Go to:  
[https://login.issso.db.com/webssso/sso\\_custom\\_multi\\_auth\\_flex\\_Logon.sso?requesting\\_slave=https://www.toolbar.autobahn.db.com/appmarket/auth\\_res?referrer%3D%252Fappmarket%252Fautobahn.jsp](https://login.issso.db.com/webssso/sso_custom_multi_auth_flex_Logon.sso?requesting_slave=https://www.toolbar.autobahn.db.com/appmarket/auth_res?referrer%3D%252Fappmarket%252Fautobahn.jsp)

The Autobahn Authentication Gateway will appear.



Deutsche Bank Authentication Gateway

Deutsche Bank Group

Request Access

Autobahn

\* Username:

Remember my Username ?

\* Password:

Login Mode: Password

Language: English

Submit Clear Form

Forgot Password?  
 Register Security Device  
 Self-Diagnostic Tool  
 Download  
 Security Awareness

**Unauthorised Access Warning:** Access to this service is prohibited unless authorised. Accessing programs or data unrelated to your job is prohibited.

**Login Modes**  
 Security options offered by Deutsche Bank.

User

Password Or G&D Smart Card Or Vasco Digipass Token

- Change the Login Mode from Password to Digipass, by selecting Digipass from the drop-down menu.



[Request Access](#)

Autobahn 

\* Username:  [?](#)

Remember my Username

---

\* Security Code:

Login Mode: Digipass

Language: English

[Register Security Device](#)  
[Self-Diagnostic Tool](#)  
[Download](#)  
[Security Awareness](#)

**Unauthorised Access Warning:** Access to this service is prohibited unless authorised. Accessing programs or data unrelated to your job is prohibited.

#### Login Modes

Security options offered by Deutsche Bank.

User

  
 Password

Or

  
 G&D Smart Card

Or

  
 Vasco Digipass Token

- Enter your Username in the login screen (A).



- Switch on your Digipass: Press and hold

- Type in your PIN code. If you make a mistake, press  to clear the digits.

- Press  when 'SELECT' appears on the display. Your Digipass will generate an eight-digit Security Code that will enable you to login.

- Enter the 'Security Code' and Click 'Submit'. Now you are securely logged into the Autobahn App Market.

## 4. Authorisation with your Digipass

To authorise your transactions, you require an eight-digit numerical code. To generate the code with your Digipass, you need to follow the six steps outlined below.

1. Switch on your Vasco Digipass: Press and hold  + 
2. Key in your PIN code if you make a mistake, press  to clear the digits.
3. Press  when “SELECT” appears on the Digipass display.
4. On the computer monitor, you will see an eight-digit number on the confirmation screen for your transaction. Key these eight digits into your Digipass. Press  if you make a mistake, press again to clear the digits.
5. Your Digipass now displays a response code consisting of eight digits. Enter these digits on your computer screen.
6. Confirm the code. You have now securely authorized your transaction.

## 5. Unlock your Digipass

In case of entering an incorrect PIN code, you will receive a notification of a failed login attempt ('FAIL 1' appears on the display). After a second failed attempt 'FAIL 2' appears in the display. Note, that after three failed attempts your Digipass is locked. A seven-digit lock code is displayed and you can no longer use the Digipass until you have unlocked it.

This requires the following six steps:

1. Phone the helpdesk. The helpdesk will ask for the seven-digit lock code. You can see this code by switching on your Digipass again. You will receive an unlock code, which you can use to unlock your Digipass.



2. Switch on your Digipass: Press and hold  +  The lock code appears on the display again.



3. Press  and type in the eight-digit unlock code.



4. Enter a new five-digit PIN code of your choice. Do not choose a code that is easy to guess, such as 12345.



5. Re-enter your chosen five-digit PIN code again.



6. 'NEW PIN CONF' appears on the Digipass display after you have successfully entered your new PIN code. Now you can use your Digipass again.



This document is for information purposes only and is designed to serve as a general overview regarding the services of Deutsche Bank AG, any of its branches and affiliates. The general description in this document relates to services offered by Global Transaction Banking of Deutsche Bank AG, any of its branches and affiliates to customers as of October 2015, which may be subject to change in the future. This document and the general description of the services are in their nature only illustrative, do neither explicitly nor implicitly make an offer and therefore do not contain or cannot result in any contractual or non-contractual obligation or liability of Deutsche Bank AG, any of its branches or affiliates. Deutsche Bank AG is authorised under German Banking Law (competent authority: German Banking Supervision Authority (BaFin)) and, in the United Kingdom, by the Prudential Regulation Authority. It is subject to supervision by the European Central Bank and by BaFin, Germany's Federal Financial Supervisory Authority, and is subject to limited regulation in the United Kingdom by the Prudential Regulation Authority and Financial Conduct Authority. Details about the extent of our authorisation and regulation by the Prudential Regulation Authority and regulation by the Financial Conduct Authority are available on request. Copyright© February 2016 Deutsche Bank AG. All rights reserved.